

Check & Ride Inspection Booklet

EGRET

www.my-egret.com

service@my-egret.com
Alter Wandrahm 6
20457 Hamburg
Germany

Check up. Scoot on.

Your checklist for safe rides free of worries. Document regular inspections and maintenance to extend your e-scooter's life, prevent accidents, and ensure the safety and performance of your e-scooter.

Serial number

WUE _____

Personal PIN code

Key number

(to be found on the key and lock cylinder)

EGRET

Inspection intervals

Please bring this inspection booklet to every inspection date.

1. Inspection

Not later than 3 months or 300 km from date of sale

RMA-No.

Date

Mileage

Checked acc. to inspection plan

Notes:

Stamp & signature

3. Inspection

Not later than 2 years or 2000 km

RMA-No.

Date

Mileage

Checked acc. to inspection plan

Notes:

Stamp & signature

2. Inspection

Not later than 1 year or 1000 km

RMA-No.

Date

Mileage

Checked acc. to inspection plan

Notes:

Stamp & signature

4. Inspection

Not later than 3 years or 3000 km

RMA-No.

Date

Mileage

Checked acc. to inspection plan

Notes:

Stamp & signature

Inspection protocol

Defects found during the inspection can be recorded under notes.

Frame & mechanics

Surface cleaning of the e-scooter

1. Inspection 2. Inspection 3. Inspection 4. Inspection

Frame checked for visible damage

Handlebar checked for fastening and damage

Steering bearing checked for play and detent points

Folding mechanism and lever checked for functionality

Re-greasing of the folding and turning mechanisms

Oiling of the lock cylinder

Components

Mudguards checked for fastening and fixation

Side/ main stand checked for fastening and functionality

All screws checked for tightness

Throttle lever checked for fixation and functionality

Electronics

Lighting, bell & horn checked for fastening and functionality

Charging function checked

Control element checked for functionality

Visual inspection of cabling

Cable routing checked for intactness

Wheels

Wheel bearings checked for functionality

Tires checked for air pressure, wear and fixation

Brakes

Brake pads checked for wear

Test ride / brake test

Brake bleeding

Brake fluid changed

For questions regarding inspection and spare parts, please contact service@my-egret.com